




tilta cage top panel by Luis Trujillo

tilta cage top panel

by Luis Trujillo

updated 18/04/2024




3D Printer Settings

Bed Adhesion
Support Structure

No brim required
Required

Preview

Place the 3D file as shown below for the best results.



3D print bed

Install

- 1 Remove the four bolts on the left hand side of the Tilta cage
- 2 Remove the Tilta cage's side panel (surrounds Pocket camera's ports)
- 3 Remove the hex-head bolt from the Tilta cage's top section
- 4 Remove the Tilta cage's top section and install new 3D printed version
- 5 Reinstall the hex-head bolt into the Tilta cage's top section
- 6 Reinstall the Tilta cage's side panel
- 7 Reinstall the 4 bolts in the cage's side panel
- 8 Install the cage onto your Pod Modded camera and test!